



T598

PlayStation®5 consoles / PlayStation®4 consoles
Consoles PlayStation®5 / Consoles PlayStation®4

















INSTRUCTION MANUAL MANUEL D'INSTRUCTIONS




USER MANUAL - MANUEL DE L'UTILISATEUR




<https://support.thrustmaster.com/product/T598p>



PS5® consoles / consoles PS5® PS4® consoles / consoles PS4®



PC**



* Sold separately / * Vendu séparément

** Also compatible with PC (Windows® 10/11). PC compatibility not tested nor endorsed by Sony Interactive Entertainment. / ** Également compatible PC (Windows® 10/11). Compatibilité PC non testée ni endossée par Sony Interactive Entertainment.

*** For more information on how to select the compatibility mode, please consult the user manual available at: <https://support.thrustmaster.com/product/T598p> / *** Pour plus d'informations sur la sélection du mode de compatibilité, veuillez consulter le manuel de l'utilisateur disponible ici : <https://support.thrustmaster.com/product/T598p>

