



42396143



42396146




42396145

42396133


42396134



42396139






42396144



42396142

42396140

42396141



Concept kód	Český název	Anglický název
42396139	Elektronika napájení RE4040	PCB power RE4040
42396140	Teplotní čidlo RE4040	Temperature sensor RE4040
42396141	Tepelná pojistka RE4040	Thermal fuse RE4040
42396142	Topné těleso RE4040	Heating plate RE4040
42396143	Víko s kabely RE4040	Lid with cables RE4040
42396144	Vnitřní víko s těsněním RE4040	Inner lid with seal RE4040
42396145	Nádoba pro vaření v páře RE4040	Steamer RE4040
42396146	Vnitřní nádoba RE4040	Inner pot RE4040
42396133	Lžíce na rýži RE3030, RE4040	Rice scoop RE3030, RE4040
42396134	Odměrka na rýži RE3030, RE4040	Measure cup RE3030, RE4040