



* GB - Content may vary according to your model. FR - Le contenu peut varier en fonction de votre modèle. DE - der inhalt kann je nach modell variieren. IT - I contenuti possono variare secondo il modello. NL - inhoud kan variëren volgens uw model. PT - o conteúdo pode variar de acordo com o modelo. ES - el contenido puede variar en base a su modelo. DK - indholdet kan variere afhængig af modellen. NO - innholdet kan variere avhengig av modellen. SE - innehåll kan variera beroende på modell. FI - sisältö saattaa vaihdella mallista riippuen. GR - το περιεχόμενο ενδέχεται να διαφέρει αναλόγα με το μοντέλο. RU - содержимое может меняться в зависимости от модели. PL - zawartość może być inna w zależności od modelu. CZ - obsah nemusí lišit v závislosti na vašem modelu. SI - obsah sa môže lišit v závislosti od modelu. TR - içerik modelinize göre farklılık gösterebilir. SK - obsah sa môže lišit v závislosti od vášho modelu.



- GB User Manual
- FR Guide de l'utilisateur
- DE Bedienungsanleitung
- IT Manuale d'uso
- NL Gebruikershandleiding
- PT Manual de Instruções
- ES Guía del usuario
- DK Brugervejledning
- NO Bruksanvisning
- SE Instruktionsmanual
- FI Käyttöohje
- GR Οδηγίες Χρήσεως
- RU Руководство пользователя

- PL Instrukcja Obsługi
- CZ Návod k obsluze
- SI Navodila Za Uporabo
- TR Kullanım Kılavuzu
- SK Návod na obsluhu



APPLY MANUAL LABEL HERE

GB - Please read the 'Instructions for Safe Use and Fittings' booklet before using your product. FR - Veuillez lire le paragraphe « Instructions De Sécurité D'utilisation Et De Raccordement » avant d'utiliser votre produit. DE - Bitte lesen Sie vor dem Gebrauch des Geräts aufmerksam die „Bedienungsanleitung zur sicheren Benutzung“. IT - Leggere con attenzione il libretto "Istruzioni Per Un Uso Sicuro E Per Il Montaggio Degli Accessori Opzionali" prima di utilizzare il prodotto. NL - Lees 'Instructies Voor Veilig Gebruik En Aansluitingen' voor u het produkt in gebruik neemt. PT - Por favor leia o manual "instruções Para Utilização E Instalação Seguras" antes de começar a usar o produto. ES - Por favor lea las "instrucciones Para Un Uso Seguro Y Para El Montaje" antes de utilizar el producto. DK - Læs venligst vejledningen "instruktioner For Sikker Brug Og Samling", inden du tager produktet i brug. NO - Vennligst les veiledningen "instruksjoner For Sikker Bruk Og Montering" før du bruker produktet. SE - Var vänlig läs "Instruktioner för säker användning" innan ni använder denna produkt. FI - Tutustu ennen tuotteen käyttöä "Isävarusteiden Turvallisen Käytön Ja Asennuksen Ohjeet" ohjeeseen. GR - Παρακαλώ διαβάστε τη ενότητα "Οδηγίες Ασφαλούς Χρήσεως Και Εξαρτημάτων" στο βιβλίο οδηγιών, πριν χρησιμοποιήσετε το προϊόν. RU - Перед использованием прибора необходимо ознакомиться с «Инструкция По Безопасному Использованию И Применению». PL - Przed użyciem produktu, proszę zapoznać się z Instrukcją Bezpiecznego Użytkowania I Akcesoriów. CZ - Před použitím výrobku si důkladně přečtěte a dodržujte pokyny v brožurě "návod K Bezpečnému Použití A Upevnění". SI - Prosim Preberite Navodila Za Varno Uporabo In Sestavo Dodatnih Priporočkov. TR - Lütfen ürünü kullanmadan önce kullanma kılavuzundaki 'güvenli Kullanım Ve Donanım' bölümünü okuyunuz. SK - Pred použitím výrobku si dôkladne prečítajte a dodržujte pokyny v brožúre "Pokyny pre bezpečné použitie".

1

Assembly steps for the cordless stick vacuum cleaner. Step 1 shows the main components: the motor unit, the main tube, the battery pack, and the motor head. The instructions show how to attach the motor head to the tube and the battery pack to the motor unit. A 'CLICK' sound is indicated for the motor head attachment. Below this, various accessories are shown, including crevice tools, motor head attachments, and a motor head cover. The bottom row shows how to attach the motor head cover to the motor head, with 'CLICK' sounds indicated for each step.

2

Charging and battery level indicators. Step 2 shows how to charge the battery pack. (A) shows the battery pack being inserted into the charging dock. (B) shows the battery pack being inserted into the motor unit. (C) shows the battery level indicator on the motor unit. The indicator shows the battery level at 16%, 50%, and 100%. A 3.5Hrs charging time is indicated. Below this, a battery level indicator is shown with a red light indicating low battery (<16%) and a green light indicating full battery (>100%).

3

Operating modes and accessories. Step 3 shows the motor unit with the power button and the turbo mode button. The motor unit has two modes: STANDARD MODE and TURBO MODE. The turbo mode button is labeled 'TURBO MODE' and 'PUSH'. Below this, various accessories are shown, including crevice tools, motor head attachments, and a motor head cover. The bottom row shows how to attach the motor head cover to the motor head, with 'CLICK' sounds indicated for each step.

4

Using the vacuum cleaner. Step 4 shows the vacuum cleaner being used on a carpet. The motor unit is shown with the power button and the turbo mode button. The turbo mode button is labeled 'TURBO MODE' and 'PUSH'. Below this, various accessories are shown, including crevice tools, motor head attachments, and a motor head cover. The bottom row shows how to attach the motor head cover to the motor head, with 'CLICK' sounds indicated for each step.

5

Maintenance and cleaning. Step 5 shows how to clean the motor head and the battery pack. The motor head is shown with the power button and the turbo mode button. The turbo mode button is labeled 'TURBO MODE' and 'PUSH'. Below this, various accessories are shown, including crevice tools, motor head attachments, and a motor head cover. The bottom row shows how to attach the motor head cover to the motor head, with 'CLICK' sounds indicated for each step.

* GB - Content may vary according to your model. FR - Le contenu peut varier en fonction de votre modèle. DE - der inhalt kann je nach modell variieren. IT - I contenuti possono variare secondo il modello. NL - inhoud kan variëren volgens uw model. PT - o conteúdo pode variar de acordo com o modelo. ES - el contenido puede variar en base a su modelo. DK - indholdet kan variere i henhold til modellen. NO - innholdet kan variere avhengig av modellen. SE - innehåll kan variera beroende på modell. FI - sisältö saattaa vaihdella mallista riippuen. GR - το περιεχόμενο ενδέχεται να διαφέρει αναλόγα με το μοντέλο. RU - содержимое может меняться в зависимости от модели. PL - zawartość może być inna w zależności od modelu. CZ - obsah směže lišit' v závislosti na vašem modelu. SI - obsah sa može lišit' v závislosti od modelu. TR - içerik modelinize göre farklılık gösterebilir. SK - Obsah sa môže lišit' v závislosti od vášho modelu.